

PUFAS Non-Woven Wallpaper Adhesive GTV

PUFAS Vliestapeten Roll-Kleber GTV

- ready-to-use
- for smooth and embossed non- woven wallpapers and for non- woven woodchip wallpapers
- ideal for digital-print wallpapers up to 200 g/m²
- for direct wall application with roller
- no splashing or dripping
- with methyl cellulose and synthetic resin
- high initial adhesion
- easy to correct
- dries to transparent finish

Instructions for use:

PUFAS Roller Adhesive for non-woven wallpapers GTV is excellently suitable for hanging fleece wallpapers and other form stable wallcoverings. With this technique the paste is applied onto the underground with a suitable role and the wallcovering is hung directly into the bed of paste. That way, form stable wallcoverings can simply and cleanly be hung with the modern technique of pasting the wall.

Technical specifications:

Components: methylcellulose, synthetic resin dispersion, additives
 Density: approx. 1.0 g/cm³
 pH-value: approx. 9.5 - 10
 Usage: Approx. 200-250 ml/m²

Surface preparation:

The surface must be dry, clean, stable and free of separating agents like dust, grease etc. Prime highly absorbent, sandy or dusty surfaces with PUFAS Deeply-Penetrating Primer LF- solvent free. We recommend a first coat with PUFAS Wallpaper Primer - White TW8 if hanging transparent fleece wallpapers or on surfaces that are not uniform in colour.

Application:

PUFAS Roller Adhesive for non-woven wallpapers is ready for use and can directly be applied from the bucket onto the underground with a short-haired role. Only coat so much of the surface as can be hung with the wallcovering in approx. 10-15 minutes.

The open time of 10-15 minutes refers to surface and room temperatures of +20° Celsius on moderately absorbent surfaces at 50-70 % relative atmospheric humidity.

Hang the wallpaper directly into the bed of paste and press it down evenly with a brush or a roller made of synthetic material. Hang the next strip seam-to-seam in the same way as described above. Wipe off any surplus paste at the seams with a clean, damp cloth.

Allow paste to dry completely before painting over if possible. High-quality fleece wallpapers can be stripped off dryly when renovating.

Note:

Please see EU safety data sheet for all safety-related data (EU-CLP)

Clean tools with water after use.

Do not use at surface and room temperatures of below +5° Celsius.

Strictly follow the wallpaper manufacturers' hanging instructions.

Considerations disposal:

Please see EU safety data sheet section 13 (EWC).

Storage:

Store in a cool and dry place! Store container well sealed!

Available sizes:

5 kg	4007954214022	021402000	REG
10 kg	4007954214039	021403000	REG