

PUFAS Non-woven adhesive PUFAS Vliestapeten-Kleister

For pasting machine, brush application and wall pasting technique

Field of application: Perfectly suitable for gluing all kinds of wallpapers onto non-woven carriers, for example, for vinyl wallpapers, embossed and textured wallpapers as well as all commercially available non-woven wallpapers. *PUFAS Non-woven adhesive* is ideally adjusted for pasting machines and brush application but can also be smoothly processed using a roller.

Product Properties:

- from pure methyl cellulose with resin for high adhesive force
- instant - ready for use after 5 minutes
- allows easy correction of wallpaper
- transparently drying
- high initial adhesion
- clean processing
- lime and cement resistant

Technical data:

Components:	Methyl cellulose, epoxy-resin powder
Bulk weight:	0.55 g/cm ³
pH value:	approx. 8
Solubility:	ready to use after approx. 5 minutes
Consumption:	approx. 200 ml/m ²

Sub-floor preparation: The sub-floor has to be dry, level, load-bearing and free from parting compounds (dust, grease and the like). Remove old, poorly adhesive wallpapers and glue-bound distempers using *PUFAS Tapetenablöser*. Mend cracks and holes with *PUFAS Interior Filler indoors* or *pufamur Super Bonding Filler SH 45*. Solidify sanding and chalking sub-floors with *PUFAS Deep Sealer LF*. Pre-paste strongly absorbing sub-floors (1:40 formulation) or prime as well. Prime coating using *PUFAS Wallpaper Primer - White* is recommended to compensate sub-floor differences in color. Water-soluble sub-floor contamination on the sub-floor which might show during wallpapering should be isolated using *PUFAS Insulating Spray White*.

Formulation: Add *PUFAS Non-woven Adhesive* quickly, while stirring vigorously, into cold clean water (see table) and keep on stirring for a short time. Stir up well once more after 5 minutes.

Application:

Application onto wallpaper back:
Apply *PUFAS Non-woven Adhesive* onto the back of the non-woven wallpaper with the pasting machine or brush. The wallpaper is then glued without soaking time.

Application onto sub-floor:
When using wall pasting technique, apply *PUFAS Non-Woven Wallpaper Paste* generously and uniformly onto the sub-floor in the width of 1-2 wallpaper webs using a short-piled roller. Place the non-woven wallpaper directly into the fresh paste bed and press on evenly and free from bubbles.

Mixing ratio:

For	Formulation	Water vol. per 200 g	200 g package enough for
Pre-pasting	1 : 40	8 l	60 – 80 m ²
Wall pasting technique using roller	1 : 15	3 l	15 – 20 m ²
Brush or pasting machine	1 : 20	4 l	20 – 25 m ²

Notes. It is essential to observe the wallpaper manufacturers' instructions for use. Do not use below +5° Celsius object and room temperature. Immediately remove adhesive residues using a damp cloth. Clean working equipment with water after use.

Storage: Store in a cool and dry place.

Article no: 200 g folded box 023401000