

PUFAS Professional PVC/CV and Carpet Adhesive TP81

PUFAS Profi-Einseitkleber TP81

- special flooring adhesive for PVC and designer flooring as well as textile coverings
- short flash-off time
- extra-strong tack
- very good wetting ability
- suitable for chair castors to EN 12529 and floor heating systems
- for absorbent and non-absorbent substrates
- solvent-free

Instructions for use:

PUFAS Professional PVC/CV and Carpet Adhesive TP 81 is suitable for gluing PVC/CV coverings in sheets and tiles, carpeting with various backings, as well as needled felt and only has to be applied to one surface. (Also glues PVC on PVC)

PUFAS Professional PVC/CV and Carpet Adhesive TP 81 is suitable for chair castors to DIN 68131 and for screeds with floor heating.

Technical specifications:

Components: plastic emulsion, calcium carbonate, natural resin ester

Density: approx. 1.3 g/cm³

pH-value: approx. 7 – 8

Usage: A2 indentations: 300 - 350 g/m²
B2 indentations: 350 - 450 g/m²

Substrate preparation:

The surface must meet the requirements of DIN 18365. Surface must be dry, stable, humidity-resistant and free from parting compounds. Level cracks, holes and irregularities with AKAPLAN Floor levelling compound. Pretreat strongly absorbent and sanding surfaces with PUFAS Deeply-Penetrating Primer LF – solvent free.

Application:

Evenly apply PUFAS Professional PVC/CV and Carpet Adhesive TP 81 to the surface using a spreading comb. Use a spreading comb with A2 indentations for PVC coverings and carpeting with foam backings. We recommend you use a spreading comb with B2 indentations for carpeting with a synthetic second backing, jute backings and needled felt.

Apply the adhesive, leave to dry for a short time and then place the flooring in the adhesive bed. The required flash-off time is approx. 10-20 minutes depending on the absorbency of the surface, the ambient temperature and air humidity. The flash-off time required for non-absorbent surfaces is approx. 30 minutes, depending on the ambient conditions.

Always follow the flooring manufacturer's laying instructions. It is possible to weld PVC floorings after 24 hours.

Note:

Please see EU safety data sheet for all safety-related data (EU-CLP)

Immediately remove any adhesive residues with water. Clean tools in water immediately after use.

Do not use if the surface and/or room temperature is below + 10° Celsius!

Considerations disposal:

Please see EU safety data sheet section 13 (EWC).

Storage:

Store in a cool place! Keep the containers tightly sealed!

Available sizes:

750 g	4007954071014	007101000	REG
750 g	4007954087916	008701092	CIS
3 kg	4007954071021	007102000	REG
3 kg	4007954087923	008702092	CIS
5 kg	4007954071038	007103000	REG
10 kg	4007954071045	007104000	REG
10 kg	4007954087947	008704092	CIS