

PUFAS High-Performance Adhesive SK

PUFAS Sicherheits-Kleister SK premium

- for pasting machines, brush application and wall-pasting with roller and spray
- also suitable for problematic substrates and new plasterwork
- very high initial adhesion
- easy to correct
- high moisture resistance
- dries to extra-transparent finish
- 5 kg container with practical dosage tub

Instructions for use:

PUFAS High-Performance Adhesive SK is suitable for all kinds of woodchip wallpapers, renovation and reinforcing fabrics, structured non-woven wallpapers, embossed and special wallpapers, vinyl and textile wallpapers as well as glassfibre.

Technical specifications:

Components: methylcellulose, additives, synthetic resin powder

Bulk density: approx. 550 kg/m³

Usage: approx. 200 g/m²

Surface preparation:

The surface must be dry, firm and free of dust and grease. Remove old and loose wallpaper and distemper PUFAS Wallpaper Remover TL. Fill in cracks and holes with PUFAS Interior filler FSI or PUFAMUR Super Bonding Filler SH 45. Pre-treat highly absorbent, sanding and chalking surfaces with PUFAS Deeply-Penetrating Primer LF – solvent free. Insulate water-soluble impurities, which may show through when wallpapering with PUFAS wallpaper primer TW 8.

Mixing ratio:

	Pre Pasting	Wallpapering machine /brush	Role/spreader
Mixing ratio	1:20	1:15	1:12:5
Quantity of water per 800 g packet	16 l	12 l	10 l
Coverage of a 800 g packet	approx. 95 m ²	approx. 65 m ²	approx. 45 m ²
Quantity of water per 1.2 kg mechanically mixed	24 l	18 l	15 l
Quantity of water per 1.6 kg mechanically mixed	32 l	24 l	20 l

Application:

Quickly pour PUFAS High-Performance SK into cold, clean water (see table) and stir briskly for a short time. Leave for 2-3 minutes and then mix again. Leave once more for 15 minutes and stir vigorously a last time.

Evenly apply the paste with a pasting machine directly onto the backside of the wallcovering or use a brush in necessary size. Hang the wallcovering following the instructions of the wallcovering manufactures. Dimensionally stable wall-coverings can also be applied directly onto the wall. Use a spreader or a short-haired lambskin role to evenly apply PUFAS High Performance SK in the width of the strips onto the underground. Hang the wallcovering into the damp bed of paste und press down evenly with a moos rubber role or a paper-hanger spatula

Note:

Please see EU safety data sheet for all safety-related data (EU-CLP)

Moisten cladded wallcoverings on the back with a wet sponge before hanging.

Strictly follow the application instructions of the wallcovering manufactures.

Clean tools with water immediately after use.

Wipe off any surplus paste on the wallpaper immediately with a damp sponge.

Do not use if surface and/or room temperature is below +5° Celsius.

Considerations disposal:

Please see EU safety data sheet section 13 (EWC).

Storage:

Store in a cool and dry place!

Available sizes:

800 g	4007954229026	022902000	REG
5 kg	4007954229040	022904000	REG